

Using The Altar with Extracts

1. Optimum Temperature Range: 500°F - 650°F
 - 500°F - 550°F: Low temperature, flavor saver, lots of terpenes, less vapor
 - 550°F - 600°F: Medium temperature, good flavor, medium vapor
 - 600°F - 650°F: High temperature, less flavor, more vapor
2. Required Accessories:
 - A rig or similar piece of glassware
 - The Crucible or another 25mm banger
 - The Orb or a carb cap
 - A dabber
 - Terp pearls if desired
5. Step-by-Step Instructions:
 1. Place The Crucible in the axial coil. Place terp pearls in The Crucible if desired.
 2. Set the desired temperature.
 3. Wait until The Crucible is hot (90 seconds to 2 minutes).
 4. Carefully pick up The Crucible by the stem near the curve and place it in your rig.
 5. Using the dabber, add your extract to the Crucible.
 6. Place the Orb on top of the Crucible.
 7. Inhale until vapor production ceases, or the taste becomes undesirable.
 8. Clean the Crucible by placing it in an alcohol bath or using cotton swabs dipped in alcohol for added cleaning.
 9. Make sure the banger is free of all alcohol residue.
 10. Repeat Steps 1-9 until you are feeling good.

Remember to exercise caution when handling the hot Crucible and Altar, and always use it in a well-ventilated area.

Always use caution when handling and using isopropyl alcohol around heat sources, electronics, and other sources of possible ignition.

I like to turn on the Altar at the beginning of a sesh or when I want to relax at home, and leave it on, with The Crucible hot and ready to go, so that I do not have to wait for the initial heat up period every dab. The Altar is designed to have low energy consumption when on, and can remain on for extended periods with The Crucible in the coil without damaging The Altar or Crucible.

NEVER LEAVE THE ALTAR ON AND UNATTENDED! treat it like a hot stovetop or a lit candle.